



Porotherm Application Guide  
Topic: Best Practices of Electrical &  
Plumbing Chasing

This document details out the electrical chasing methods and Anchor installation methods on Porotherm walls

Steps for Electrical Chasing.

Step:1

Mark the layout



Step: 2

Chase the wall with a dry cutter



Step: 3

Chip off the chased surface with hammer & chisel



Step: 4

Nail at the masonry joints only



Step: 4

Place the pipes in conduit



Step: 5

Pipes/ Electrical box fixed after chasing



Plumbing

Note:

- Use of cutting machines is mandatory, Direct chasing with chisel and hammer is not recommended
- Nails should be hammered in masonry joints only.
- Excess chasing should be avoided.
- **Recommend use of plastering mesh at large and deep** chasing areas e.g. Distribution Box area to avoid cracks or multiple pipe conduits.