



Porotherm Application Guide
Topic: Best Practices of Smearing

Step:1

Pre - wetting inner brick surface



Step: 2

Pouring concrete /mortar upto 100mm



Step: 3

Smearing



Step: 4

Constructed wall by smeared bricks



Procedure and Tips:

1. A small amount of water to be poured in the brick voids.
2. Cement concrete/Cement mortar using 10 mm or down size aggregate should be prepared.
3. Cement concrete/cement mortar to be filled/ poured uniformly into all perforations.
4. Concrete/mortar should be firmly filled to a minimum depth of 100mm.
5. Ensure adequate curing of the filled mortar/ concrete.